



GTS6 FLASHLIGHT MANUAL



WARNING:

1. Do not shine directly in the eyes, the powerful LED light will damage the eyes immediately.
2. If the battery is not used for a long time, please charge and discharge it every 3 months to keep the battery in good condition.
3. It is normal to use the lights for a long time to heat up.
4. When the indicator light shows low power, please charge the battery as soon as possible.
5. Please keep the battery away from water, moisture and drop etc.
6. To avoid damage to the surface of the flashlight, please do not expose the flashlight to sunlight, water, chemicals, corrosive gases or any other oxidizing environment frequently.
7. Before use, please tear off the transparent film on the battery surface before use.

INSTRUCTIONS FOR USE



Charging port



• Button

1. Press the button to turn on the strong light, and continue to press (Strong Light-Medium Light-Low Light-Strobe-SOS-Off) to cycle through five modes; press and hold any mode for about 1.5 seconds to turn off the light source.
2. The red indicator light is always on when charging, and the blue indicator light is always on when fully charged.

PRODUCT PARAMATERS

Model	GTS6	Power	7w
Charging ways	Type-C	Weight	108G
Battery	Built-in 18650	Size	137*31*24mm
Mode	Strong Light-Medium Light-Low Light-Strobe-SOS-Off		

APPLICATION SCENARIO



Camping



Mountaineering



Capture



GO fishing



Rock climbing



Cycling



Motion



Construction



Explore



Repair

Warranty card

User name: _____

Phone number: _____

E-mail: _____

Address: _____

Other Contacts: _____

Release Date: _____

SIZE:70*105