



# S3 SERIES FLASHLIGHT

## INSTRUCTION MANUAL



### WARNING:

1. Do not shine directly in the eyes, the powerful LED light will damage the eyes immediately.
2. If the battery is not used for a long time, please charge and discharge it every 3 months to keep the battery in good condition.
3. It is normal to use the lights for a long time to heat up.
4. When the indicator light shows low power, please charge the battery as soon as possible.
5. Please keep the battery away from water, moisture and drop etc.
6. To avoid damage to the surface of the flashlight, please do not expose the flashlight to sunlight, water, chemicals, corrosive gases or any other oxidizing environment frequently.
7. Before use, please tear off the transparent film on the battery surface before use.

### INSTRUCTIONS FOR USE



1. S3/S3-A Heavy press (full press) the tail button to turn on/off the light source, light press (half press) to adjust the modes, and the five modes (Strong Light-Medium Light-Low Light-Strobe-SOS) will cycle in sequence.
2. The push-pull lamp head can realize telescopic focusing.

## PRODUCT PARAMETERS

Model	S3	S3-A
Power	3W	3W
Battery	1*18650	1*18650/3*AAA
Runtime	About 2.5H	About 2.5H
Charging ways	Charger	Charger
Weight	58G	70G
Material	Aluminum alloy	Aluminum alloy
Waterproof	IP44	IP44
Size	115*23*26mm	117*30*28mm
Light Modes	Strong Light-Medium Light-Low Light-Strobe-SOS	

As our series of products will be continuously upgraded, this manual can still be applied to the subsequent series of products.

## APPLICATION SCENARIO



Camping



Mountaineering



Capture



GO fishing



Rock climbing



Cycling



Motion



Construction



Explore



Repair

# Warranty card

User name: \_\_\_\_\_

Phone number: \_\_\_\_\_

E-mail: \_\_\_\_\_

Address: \_\_\_\_\_

Other Contacts: \_\_\_\_\_

Release Date: \_\_\_\_\_